


CP04 AXIAL-FLOW PUMP CURVES



FLOW IN U.S. GALLONS PER MINUTE (GPM)

PLOT YOUR POINT: Follow the flow in U.S. gallons per minute required horizontally on the chart to your GPM flow required; then follow up to your total head in feet required.

The location of the point plotted on the chart determines the horsepower of pump required.

Carry Pumps, Inc. · 1360 Prospect Ave. · Caro, MI 48723 www.carrypumps.com · 800-492-2779 · sales@carrypumps.com